



Crime Prevention Products

Copsham House, 53 Broad Street,
Chesham, Buckinghamshire, HP5 3EA
Tel : 01494 792592 Fax : 01494 792590



CHAPERONE HANDHELD UV TORCH

PRODUCT CODE: CPP-CD2A

Fitting the batteries: Requires 4 x AA Batteries (Not included)



Step 1:

Hold the lamp in your LEFT hand with the UV bulb in your palm. The open battery compartment needs to be at the top.



Step 2:

Put two (2) AA Batteries into the column closest to your left hand palm. (Positive side up).

Make sure they are BOTH positive side up.



Step 3:

Now place two (2) AA Batteries into the column furthest away from your left hand palm. (Positive side down.)



Step 4:

Once all four (4) batteries have been fitted replace the top and it's ready to use!

Make sure they are BOTH positive side down.

To change the UV tube:

Simply 'click-out' the protective clear cover from the side of the lamp. Carefully twist the UV tube slightly in a clockwise or anti-clockwise direction so that it can be removed easily. Then replace it with a new UV tube. Push the clear plastic cover carefully back into place by squeezing the sides in slightly. Note that the white bulb is NOT replaceable.

