



Crime Prevention Products

Copsham House, 53 Broad Street,
Chesham, Buckinghamshire, HP22 5WH
Tel : 01494 792592 Fax : 01494 792590



SECURES IN SECONDS

DIRECTIONS FOR FITTING
KWC WHEEL CLAMP



STEP 1

POSITION THE CLAMP AROUND THE TYRE BY HOOKING ONE ARM THEN THE OTHER AROUND BASE OF TYRE.

PULL COVER PLATE UP SO THAT IT IS CENTRAL TO THE WHEEL HUB AND THE CLAMP ARMS ARE TOUCHING THE GROUND.



STEP 2



STEP 3

HOOK THE THIRD ARM OVER AND BEHIND THE TYRE AND SLIDE DRILLED BAR INTO COVER PLATE, ADJUST ARM UNTIL HOLES LINE UP AND THE LOCK CLICKS INTO PLACE.